

Space Arm, (SA, SAT)



Rugged external space arm. The rewriter is well adapted accessory to printers in the **Intermec EasyCoder** range.

The Space Arm is designed for holding the printer. It can be moved 360 degrees, and it makes more space for you.

Space Arm are made in two different base version,

Space Arm (SA), with no "Tilt" function, SA model
Space Arm (SAT), with "Tilt" function, SAT model

- External space arm for printer.
- Adapted for the **Intermec EasyCoder**.
- Making more space under printer.
- Easy installation.



